


# **Manual Activation of Windows®**

# Procedure


1. Open the Charm menu from your device and select 'Settings'




2. Select 'Change PC settings'






3. From the PC setting screen, select 'Activate Windows®'




4. Select 'Activate by Phone' if you're unable to activate Windows® online



5. From the dropdown, select India and then select 'Next' to continue



6. You will now be taken to a screen with toll & toll free numbers



7. Call any of the numbers and listen carefully to the automated system and select your choices

- 1 - Select the option for Home User (press 1 on your phone)
- 2 - Select the option for Product activation (press 1 on your phone)
- 3 - Select the option to Activate a Microsoft Windows® product ((press 1 on your phone))
- 4 - Listen to the automated information and then press "\*" when you're ready to proceed
- 5 - As and when required, enter all the numbers of a ll 9 sets of the installation ID
- 6 - Recheck your installation ID after all the 9 sets have been entered.
- 7 - The system will now automatically generate a 48 digit Confirmation ID which will be read out to you in blocks of 6 numbers.
- 8 - Select 'Enter Confirmation ID' and type in the 48 digit confirmation ID which you have just received.
- 9 - After a few moments, your Windows® Device will now be activated!

Microsoft and Windows are either registered trademarks or trademarks of Microsoft Corporation in the United States and/or other countries.

Notion Ink Cain and Notion Ink are registered trademarks of Notion Ink Design Labs Pvt Ltd.

Copyright © 2014 Notion Ink Design Labs Pvt. Ltd. All rights reserved.